

Pilot EasyTel Programming Procedures.

Auto-Search

- Turn your device on.
- Press C button until the LED lights up
- Press and hold the Power button (the LED will switch off then flash twice)
- With remote control directed to device, Release Power button to begin search mode. The LED will begin to flash ON and OFF during search mode
- Immediately press any button when device switches OFF. The LED will flash 4 times and switch OFF. This will stop the search mode
- Press Power button to switch device ON. Check to see all other functions work OK.

Manual Search

- Press C button until LED switches ON
- Enter the four digit code using corresponding numbers on keypad as per below:

- 1 : Volume Down (-)
- 2 : Program Up (P+)
- 3 : Volume Up (+)
- 4 : Program Down (P-)
- 5 : Mute



Manual Entering Of Codes: <http://www.wesccomponents.com/pilot/>

✓ LIST ACCORDING TO TV BRANDS

TV BRANDS	TV CODE
A.R. SYSTEMS	1342-1344
ACCENT	1424-2132
ADMIRAL	1232-1424-2321-2333-2422
AGASHI	1111-1112
AIKO	1343-1424-2114
AiM	1111-1112-1344-1432
AIWA	3124
AKAI	1111-1112-1124-1343-1421-1424-1432-2113-2114-2133-2142-2234-2242-2312-2331-2332-2343-3221
AKI	1343
AKURA	2132
ALBA	2332
ALBIRAL	1111-1112-1331-1342-1344-2123-2132-2232-2332
ALHORI	1343
ALLOGRAN	1343
AMPLIVISION	1343-1344
AMSTRAD	1424-2132-2333
ANITECH	1111-1222-1424
ANTECNO	2114
ALLOGRAN	1343
ARC EN CIEL > THOMSON	
ARISTONA > PHILIPS	
ARÇELİK	1114-1142-2142-2221-2332-2343-2412
ART TECH	1111
ASA	1132-1213-1214-1224-1231-1241-2321
ASBERG	1111-1112-1222-2234
ASTRA	1424
ASTRO SOUND	1111-1344-2332
ASTON	2432
ASUKA	2114-2332
ATAKI	2121
ATLANTIC	1111-1112-1121-2334
ATORO	1424
AUDIOSONIC	1111-1112-1114-1142-1342-1343-1424-2114-2132-2311
AUDIO STAR	2114-2121
AUDIOTON	1424-1343-2114-2121
AURORA	1232-1343-1424-1432
AUSIND	1144
AUTOVOX	1111-1112-1213-1221-1223-1333-1343-1424-2321-3123

TV BRANDS	TV CODE
AWA	1111-1112-1343-1413-1424-1432-2242
BAIRD	2242-2341
B. & OLUFSEN	1111-1112-1232
BARCO	1232-1314-1321-1323-2123-2341
BASIC LINE	2114-2321-2324
BAUR	1111-1112-1124-1131-1411-2321-2323-2331-2421-3231
BAZIN	1242-1343-2322
BEKO	1111-1112-1114-1142-2142-2221-2332-2343-2412-2413-2433
BEKOTEKNIK	1114
BEON	2234
BIFONIC	1343-1424
BIGSTON	1424-2132
BLAUPUNKT	1124-1131-1141-1342-1413-1442-1444-2113
BLAUSONIC	1343
BLUE STAR	2332
BRANDT	2221
BRENDSTAR	1424
BRIONVEGA	1111-1112-1232-1234-1314-1334-1341-2223-2333-3123-3141
BRITANNIA	1343-2321
BRUNS	1232-2122-2224-2331
BSR	2322-2331-3111-3121
BUSH	2323-2332
CAPSONIC	2132
CASIO	1111-1112
CBM	1222
CENTURY	1232-1331
CGE	1111-1112-1114-1222-1313-1331-1424-1443-2114-2234-2322-2332-2334-2422
CGM	1111-1112-1114-1142-1424-2121-2132
CIE	1424-1432-2114
CIHAN	1111-1112-2332
CLARIVOX	1111-1112-1144-1232-1331-1342-1344-2244-2311
CLATRONIC	2434
COMPUTRON	1111-1112-1424
CONCORDE	1424
CONDOR	1111-1112-1222-1424-2132-2234-2334

✓ LIST ACCORDING TO TV BRANDS

TV BRANDS	TV CODE
CONIC	1421
CONTEC	1343-1413-1424-2132
CONTI	1111-1112
CONTIN.FR	3144
COSMEL	1424-2311
COSMOS	1111-1112-1424
CROSLLEY	1133-1222-1232-1313-1331-1443-2321
CROWN	1111-1112-1114-1133-1142-1222-1424-2114-2121-2132-2133-2234
CRYSTAL	1111-1112
CS ELECTRONIC	2114
CTC	2434
CTC CLATRONIC	1111-1112-1114-1222-1331-1343-2114-2132-2232-2234
CYMATIC	1342-1343-2332
DAEWOO	1111-1112-1331-1333-1343-1424-1432-1434-2114-2242-2312
DANSAI	1421-2132
DAWA	1111-1112
DE GRAAF	2323
DECCA	1111-1112-1342-1343-1412-1424-2242
DENVER	1424
DESMET	1111-1112-1342-1424-2332-2334
DIAMOND	1424-1432
DIXI	1424
DOMEOS	1111-1112
DOMOH	1111
DORIC	2321
DUAL	1111-1112-1122-1132-1331-1343-1424-2321-2331-2332-2333-3221
DUAL TEC	3111
DUMONT	1111-1112-1132-1214-1222-1224-1231-1232-1442-2232-2234
DYNAMIC	1424
EDAN LINE	1111-1112
ELBE	1123-1342-1343-1344-1413-2212-2223-2332-2333-2414-2422
ELECTRO TECH	1424
ELEKTRONSKA	1342-2332
ELIN	1111-1112-1132-1343-1424-2331
ELITE	1442-2334
ELMAN	2232-2332-3111
ELTA	2122

TV BRANDS	TV CODE
EMERSON	1111-1112-1114-1222-1224-1232-1331-1343-2132-2232-2332-2334
ENGEL	2332
ETRON	1424-2133-3211
EUROCOM	2332
EUROMAN	1111-1112-1133-1343
EUROPHON	1331-1342-1343-2232-2243-2332
EXPERT	1121-2213-2321
FAGOR	1441
FALCON	1424
FENNER	1111-1112-1424-1432
FIDELIS	1111-1112-1343-1421-1424
FIDELITY	1322-1343-1421-2114-2131-2133-2221-2321-2332
FILSAI	1343-1424
FINLANDIA	2322-2323
FINLUX	1132-1144-1213-1214-1224-1231-1333-1342-1424-2232-2234-2242-2321-2331-3143
FIRST LINE	1111-1112-1331-1343-1424-2321-2332
FISHER	1114-1132-1232-1343-1413-1414-1423-2224-2321-3231
FORMENTI	1111-1112-1114-1144-1222-1232-1342-1343-1424-1442-2132-2232-2234-2321-2322-2332-2334-3111
FORTRESS	1232
FRONTECH	1333-1421-1424-2323-3111
FUJITEC	1111-1112
FUJITSU	1231-2114-2331-2333
FUMEO	2331
FUNAI	1424-2132
GALACTEX	1343-2132
GALAXIS	1111-1112
GALAXY	1114-1214-1222-1343-2234
GALERIA	1424
GBC	1111-1112-1331-1413-1424-1432-2114-2121-2133-2242-2321-2332
GE	2221
GEBER	2321-2324
GEC	1311-1342-1343-1413-2242-2321-2322-2323
GELESO	1331-1342-1424-1432-2114-2321-2332
GENERAL STAR	2424

✓ LIST ACCORDING TO TV BRANDS

TV BRANDS	TV CODE
GENERAL TECHNIC	1424
GIANT	1111-1112-1343-2443
GITEM	1111-1112-1131-2142-2221-2321 2324
GM	1424-2132
GMG	1424-2132-2234
GOLDSTAR	1111-1112-1122-1131-1212-1333 1343-1421-1424-2224-2233-2323 2331-2332-2424
GOODING	3144
GOODMANS	1111-1112-1424-1432-2332
GORENJE	1114-1133-2321
GPM	1424-2114
GRANADA	1111-1112-1144-1342-1343-1413 2113-2123-2321-2322-2323-2343 2423-2443
GRANDIN	2213-2321-2332-2334
GREAT WALL	2132
GRUNDIG	1111-1112-1124-1131-1221-3144
GRONIC	1111-1112-1124-1131-1144-1221 1343-2332-3144
GTT	2234
HAMERSTEIN	1343-2132-2134
HAMPTON	1343
HANIMEX	2114
HANSEATIC	1111-1112-1131-1342-1343-1413 1424-2321-2323-2331-2334
HANTAREX	1111-1112-1342-1424
HCM	1343-1424-2121-2122-2332
HEMMERMANN	1343-2321
HEXA	2244-2332
HIGASHI	1343
HILINE	1424-2132-2133
HINARI	1111-1112-1412-1421-1424
HISENSE	2323-2341
HITACHI	1343-1413-1421-2142-2212-2233 2321-2322-2323-2331-2332-2412 2413-2444-3132
HOSHAI	2121
HYPER	1111-1112-1333-1343-1424-1433 2114-2121-2133-2322-2332-2444
HYPSON	1111-1112-1424-2132
HYUNDAI	1111-1112-3213
IBERVISAO	2321-2332
ICE	2114-2132-2133

TV BRANDS	TV CODE
IEG	1343
IMPER	1111-1112-1424-2114-2132-2433
IMPERIAL	1111-1112-1114-1222-1313-1331 1443-2132-2234-2322-2332-2422
INDESIT	2143
INFREM.CONTR.	3143
INNOHIT	1111-1112-1212-1331-1342-1343 1421-1424-2114-2121-2133-2242 2321
INTERDISCOUNT	1111-1112-1411-2142-2221
INTERFUNK	1111-1112-1241-1444-2123-2142 2234-2321-2324-2331
INTERVISION	1111-1112-1331-1333-1343-2224 2242
IRRADIO	1111-1112-1144-1212-1333-1421 1424-2114-2132-2133
ISKRA	1142-1342-1343-2232-2332
ITC	1343-2332
ITL	1424
ITT SCHAUB LORENZ	1111-1112-1424-2321-2332
ITT / NOKIA	1111-1112-1432-2234-2321-2322 2323-2324-2331-2332-2333-2341 2421-3143
JET POINT	1111-1112-2134
JINLIPI	1424
JOHNSON	1343
JVC	1413-2131-2133-2134-3212
KAISER	1111-1112
KAISUI	1111-1112-1343-1424-2114-2121 2234-2312
KAMAR	1423
KAMBROOK	1111-1112-1343-2132-2142-2224
KAMOSONIC	1343
KAPSCH	1121-1132-2321
KARCHER	1111-1112-1231-1343-1344-1424 2121-2243-2323
KENDO	1122-1331-1343-1424-2223-2232 2321-2331-2333-2422
KENNEDY	1122-1331-2223-2321-2331-2333 2422
KERION	1111-1112
KIC	1343
KIOTA	2132
KITT	1343
KIYOGIN	1111-1112

✓ LIST ACCORDING TO TV BRANDS

TV BRANDS	TV CODE
KLARMAX	1342-1343-1344-2122-2123-2332
KNEISSEL	1123-2422
KOBIC	1424
KOENIG	2321-2334
KOERTING	1111-1112-1114-1232-1311-2321 2334
KOLSTER	1111-1112-1331-1333-1343-1344 2232-2332
KONTAKT	3144
KOTRON	2132
KRONNE	1343-2332
KUBA ELECTRONIC	3231
KYOTO	1342-1343-2332
LAVIS	1342
LEADER	1424
LEGEND	1111-1112-1343-1424-2132-2311
LENCO	1432-2232-2331
LENOIR	1111-1112-1343-1424-2121-2321
LEYCO	1111-1112-2132-2242-3111
LIESENKOTTER	1111-1112-1442
LIFE	1424
LLOYD'S	1144-1343-1424-2132-2321
LOEWE	2321
LOEWE OPTA	1111-1112-1132-1234-1241-1342 1343
LOGIK	1324-1412-2131
LUMA	2112-2321-2331-2333
LUXOR	1212-1333-1343-2233-2321-2322 2323-2331-2341-3132
M.ELECTRONIC	1111-1112-1132-1214-1224-1231 1331-1333-1424-1432-2111-2321 2331-3231
MAAZ	2122-2123
MAGNADYNE	1111-1112-1232-1331-1342-1424 2232-2234-2321-2332
MAGNAFON	1111-1112-1144-1214-1342-1343 2232-2321
MANESTH	1111-1112-2324-2334
MARANTZ	1111-1112
MARECH	2334
MARK	1142
MASCOT	1331
MATSUI	1111-1112-1343-1412-1424-2132 2321-2323-2332-2342-3111-3121
MATSIKA	1343-2132

TV BRANDS	TV CODE
MAXAM	1424-2132
MAXELL	1424
MAXWELL	1111-1342-2123-2232
MCE	1424
MEGA	1111-1112
MEMPHIS	2311
MERCURY	1343-1424-2132
METZ	1124-1131-1134-1141-1241-1243 1244-3223
MGA	1111-1112-1432-2114-2132
MICRON	1343
MINERVA	1124-1131-1144-2111-3144
MITRONIC	1421
MITSUBISHI	1111-1112-1124-1241-1412-1413 1424-1432-2443-3113
MIVAR	1123-1143-1211-1212-1332-1342 1343-2313
MTC	1114-2332
MULTITECH	1111-1112-1114-1331-1333-1342 1343-1412-1413-1424-2114-2122 2232-2332
NAGEL	1312
NAGOYA	2322
NARITA	1432
NATIONAL PANASONIC	2113
NEC	1344-1412-1413-1424-1432-2431
NECKERMANN	1111-1112-1114-1131-1241-1343 1411-1442-1444-2223-2321-2323 2334
NEI	1111-1112-2311-2332
NEWMAR	1343-2332
NEWTECH	1111-1112-1343
NIKKAI	1343-1421-2132-2233
NIKKO	1343-1421-2132-2233-2311
NOBLEX	1413-1414-1423-1424-1431-1432
NOBLIKO	1144-1214-1222-1331-1343-2232
NORDMENDE	1233-1322-1323-2142-2212-2221 2321-3122
NORDWAY	2332
NOVATRONIC	1111-1112-1424-1432-2132
OCEANIC (ITT)	2144-2213-2321-2322-2323-2324 2331-2341
OCTAL	1343
OKANO	1114
OLYMPIC	1424

✓ LIST ACCORDING TO TV BRANDS

TV BRANDS	TV CODE
ONCEAS	1331-1343-1424
ONWA	2132-2133-2234
OR-ON	2121
ORAVA/OTF	1111-1112-1424
ORION	1111-1112-1412-1421-1424-2132 2214-2314-2321-2344-2411-3111 3121-3142-3224
ORION HUNGARY	1111-1112-2131-2314-2322-3132 3134
ORMOND	1342
ORSOW'E	1111-1112-1342-2132
OSAKI	1111-1112-2132
OTHER LINE	1342
OTTO VERSAND	1111-1112-1124-1131-1333-1343 1411-1413-1424-2113-2122-2221 2321-2323-2331-2334-3231
PAEL	1144-1343
PALLADIUM	1114-2223
PALSONIC	1111-1112-1343-1421-2114-2132
PANAMA	1111-1112-1331-2132
PANASHIBA	1424
PANASONIC	1131-2113-2321-2442-3112
PANAVISION	2132
PANAVOX	1424-2321
PANORAMIC	2142
PATHE CINEMA	1114-1342-1343-1344-2244-2332 2334
PATHE MARCONI	1322-1323-2111-2142-2212
PAUSA	1424
PCM	1111-1112
PERSHIN	1144-2244
PHILARMONIC	1343
PHILCO	1111-1112-1114-1222-1232-1313 1331-1413-1424-1443-2234-2321 2322-2332-2422
PHILIPS	1111-1112-1131-1232-1241-1343 1344-2112-2123-2124-2142-2321 3131-3222-3231
PHONOLA	1111-1112-1232-1343-2123-2124 3222
PIONNER	1111-1112-2142-2331
PLANTRON	1424
PRANDONI PRINCE	1144-1331-1342-2321-2322
PRIMA	1343-1421-1424-2132
PRINCESS	1421-1424

TV BRANDS	TV CODE
PROFEX	1222-1424-1442-2331
PROFILO	1111-1112-1342-2221-2332
PROLINE	2344
PROTECH	1111-1112-1142
PYE	1111-1112-1432-2123
QUALCRAFT	1421-2114
QUASAR	1144-2232-2321-3111
RADIOLA	1111-1112-2112-2123
RADIONETTE	1132-1231-2321
ROB,ELECTRONIC	1232-2224
QUELLE	1111-1112-1124-1132-1144-1212 1213-1214-1224-1231-1333-1343 1411-1412-1414-1421-1442-1443 1444-2132-2321-2331
RADIOTONE	1132-1231-2321
RBM BANK	2321-2323-2332
RECOR	1111-1112-2132
REDIFFUSION	2321-2331
REGENTE	1424
REX	1111-1112-1121-1122-2221-2223 2321-2331-2332-2333-2422
RFT	1142
RIZ	2332
ROADSTAR	1111-1112-1421-1424-2114-2121 3221
ROWA	1343-1424-2132
ROWSONIC	1343
ROYAL	1424
RTF	1232
SABA	1111-1112-1241-1322-1323 1342-1424-1432-2142-2212 2221-2321-2332-2324-2432 2434-2441-3122-3232
SAISHO	1343-1344-1412-1432-2114-2343 3111-3121
SAKURA	1424
SALORA	1111-1112-2233-2321-2322-2323 2324-2331-2341-3143
SAMBERS	1144-1212-1214-1222-1342-1344 2232
SAMSUNG	1111-1112-1113-1114-1212-1343 1421-1423-1424-1431-2134-2242 3111
SANDRA COLOR	1342-1343
SANKYO	1422
SANSUI	1111-1112-1424-2121-2133-2341

✓ LIST ACCORDING TO TV BRANDS

TV BRANDS	TV CODE
SANYO	1114-1132-1232-1343-1412-1413 1414-1424-2224-2242-2321-2341 2421-2423-2444
SAR	1111-1112-1343-2332
SCHAUB LORENTZ	1111-1112-1114-1424-1432-2121 2321-2331-2341
SCHINEDER	1111-1112-1122-1221-1333-1343 1424-2112-2114-2123-2133-2321 2322-2323-2332-2333-3111-3231
SEG	1111-1112-1222-1331-1343-2232 2332
SENTRA	2343
SCOTT	1111-1112-2334
SELECO	1111-1112-1121-1122-1333-1413 2221-2223-2321-2331-2332-2333 2422
SET	1111-1112-2332
SHARP	1413-2122-2131
SHIVAKI	1111-1112
SHOV	1111-1112-1424-2132
SIAREM	1232-1342-2232-2321
SICATEL	1344
SICE	1124
SIDEC	2332
SIEL	1222
SIEMENS	1124-1131-1144-1342-1414-1421 1442-1444
SILMA	1111-1112
SILVA	1424
SILVER	2114-2132
SIMTEL	1111-1112-2114-2121-2132
SINGER	1111-1112-1232-1331-1342-1343 1424-2213-2232-2321-2422
SINUDYNE	1111-1112-1232-2114-2214-2232 2321-2333-2344-2411-3111
SIREL	1342
SKAY	2121
SLAVA	1343
SOLAVOX	2233-2321-2331
SONITRON	1343
SONOKO	1111-1112-1343-1424-2121-2132
SONTEC	1111-1112-1114-1333
SONY	1411-1412-1413-2142
SOUNDMASTER	1424
SOUTHERN CROSS	1333

TV BRANDS	TV CODE
SOWTECH	1111-1112
STANDARD	1331-1343-1424-2114-2334
STARLITE	1424
STARLUX	1424
STERN	1121-1122-2223-2321-2331-2333
STVI	1343-2332
SUNKAI	2121-2411
SUNNY	2133
SUNWATT	1111-1112
SUPERLA	1342-2332
SUPERSONIC	2121
SUPERTEC	1111-1112-1424-2114
SUPRA	1424-1432-2424
SUPREME	1214
SYC LINE	1424
SYDNEY	1342
TADISTAR	2234
TALENT	1124
TANDBERG	1134-1213-1234-1244-1342-2142 2212-2333
TANDY	2213-2322-2323
TASHIKO	1343-2323
TATUNG	1111-1112-1124-1342-1343-1412 2231-2242
TEAK	1111-1112-1343-1424
TEC	1343
TECHNICA	2114
TECHNICS	2113-3112
TECHNOL	1111-1112-1343-1424-1432-2132
TEDELEX	1111-1112-1343-1424-2332
TEINEL	1111-1112-2332
TEKNANT	1111-1112-1424
TELEAVIA	1322-1323-2111-2142-2212-2222
TELEFAC	1424
TELEFUNKEN	1111-1112-1324-1331-1342 1424-1431-1432-1443-2142 2143-2211-2222-2231-2332 2434-2441-3114-3232
TELEOPTA	1424
TELEPOINT	1111-1112
TELESTAR	1424-2132
TELETECH	1331
TELEVIDEON	1111-1112-1114-1343-2321-2322 2334
TELKOM	1111-1112-2332
TELRA	1111-1112-2221-2332

✓ LIST ACCORDING TO TV BRANDS

TV BRANDS	TV CODE
TEMPEST	1343-1424-2114
TENSAI	1111-1112-1132-1231-1331-1343 1421-1424-1432-2114-2224-2232 2243-2334
TESLA	1344
TETRA	2232-2334
THOMSON	1144-1322-1323-2111-2123 2141-2142-2212-2221-2222 3134-3144-3232
THORN	2343-3143
TOBISHI	1343-1424-2114-2132
TOBO	1424
TRIAD	1111-1112-1344
THORN FERGUSON	1111-1112-1124-1131-1132-1144 1224-1231-1324-1342-1343-1344 1411-1413-1414-2131-2132-2134 2142-2213-2221-2241-2242-2321 2322-2324-2331-2333-2341-2342 2343-2421-2423-2443-2444-3114 3212
TOKAI	1111-1112-1424-2121-2132
TOKYO	1111-1112-1424-2132
TOMITA	1343
TOPVISION	2332
TOSHIBA	1111-1112-1413-2342-2343
TRANSCONTINENTS	1342-2321
TRANSONIC	1111-1112-2132-2234
TREVI	1424-2121
TRISTAR	2131
TRIUMF	1214-3111
TRIVISION	1424
UHER	1121-1221-2322-2334-3231
ULTRAVISION	1322-1344
ULTRAVOX	1111-1112-1232-1331-1343-2232 2321-3222
UNIC RADIO	1114-1342-1343-2331-2332
UNIVERSUM	1111-1112-1124-1131-1132-1133 1144-1212-1213-1214-1224-1231 1333-1343-1411-1412-1413-1414 1421-1424-1442-1443-1444-2132 2321-2324-2331-2332
UNIVOX	1111-1112-1232-1331-1344-2321 2332
URANYA	1111-1144-1342-1424-2232-2334
UTAX	1343
VANGUARD	1343-1424-2323
VECO	1111-1112-1424

TV BRANDS	TV CODE
VESTEL	1111-1112-1114-1331-1422-2131 2323-2332-3214
VEXA	1111-1112-1343-1424-2121-2323
VICEROY	1343-1421-2132
VIDEOLOGIC	1343-2114
VIDEOMAC	1343-2132
VIDEOTON	1333-1342-1343-2234-2322-2323 2332-3132
VIDIKRON	2334
VIDION	1424
VISA ELECTRONICS	1222-1343-2332
VISION 2000	1111-1112-1424
VISIorex	1342
VISTAR	2324-2331
VOXSON	1144-1232-2232-2321
WALKIE	1122
WATSON	1111-1112-1442-2132-2321-2334 3111
WATT RADIO	1343-1344-2232-2243-2321
WEGA COLOR	1413
WEGA VISION	1413
WEGAVOX	1331-1424-2234-2332
WELBLICK	1111-1112-2334
WESTON	2332
WHITE WESTINGHOUSE	1111-1112-1114-1222-1343-2232 2234-2332-2334
WINSTON	1111-1112-1424-2121
WORLD TECH	1111-1112
YOKO	1111-1112-1343-1424-2132-2142
YORK	2114
YUMATU	1111-1112-1424-2132-2234
ZAMPA	2321
ZANUSSI	2321

<http://www.wescomponents.com/pilot/>
<http://www.sarelektronik.com/>